

## Control Panel Operation Instructions:



### 1. On/Off

Press to activate controls, backlit LED white light will come on; all hydrotherapy options can now be used. Selecting an option changes back light from white to blue to show the function is now active.

### 2. Chroma Therapy

This button activates the chroma therapy light.

- 1st Press -Turns on the chroma therapy for duration of 20 min.
- 2nd Press: Stops cycling through the colors so light stays on the selected color.
- 3rd Press: Turns off the chroma therapy light When in cycling mode each color changes after 8 sec.

### 3. Seat Warmer

This button activates the seat warmer.

- 1st Press -Turns on the seat warmer for a duration of 20 min.
- 2nd Press: Turns off the seat warmer.

### 4. Air Jets

This button activates the air jets.

- 1st Press: Turns on the air jets for duration of 20 min.
- 2nd Press: Turns off the air jets.

### 5. Variable Speed Water Jets


This button activates the variable speed water jets for duration of 20 min.

Press to cycle between the 4 different speed settings:

- 1st Press: Starts water jets in high mode
- 2nd Press: Switches water jets to low mode
- 3rd Press: Switches water jets to pulse mode - low to high
- 4th Press: Switches water jets to pulse mode - high to low
- 5th Press: Turns off the water jets
- The water jet button will blink if pressed before the water reaches the water sensor level, once water reaches this level the jets will activate.

# OH5129 Sonoma

FULLY LOADED



## WALK-IN BATHTUB

Owner's Manual



*Important: Read this manual before installing this product. There is important product safety information in this manual, so please be sure to read it thoroughly.*